



# UPGRADING SIGN CONTROLLER

## FROM LEGACY MODEL RM-32 TO CURRENT MODEL RM-32D

FOR CONNECTION TO DS-LIVE™ | SIMPLIFIED UPGRADE WIRING DIAGRAM

Fitted with 4G Module



XLP-16V (Housing)  
SXF-41T-P0.7 (Pins)  
PCB (Side Entry Header)  
S16P-XL-HDS(LF)(SN)

## JST CONNECTOR – 16 PIN

Pin 1	Do not connect		
Pin 9	Do not connect		
Pin 2	Radar +VE 12 V <b>switched output</b>		<b>RED</b> pin 1 Radar JST-4
Pin 10	Radar GND		<b>BLACK</b> pin 4 Radar JST-4
Pin 3	Radar RS-232 TX		<b>YELLOW</b> pin 3 Radar JST-4
Pin 11	Radar RS-232 RX		<b>GREEN</b> pin 2 Radar JST-4
Pin 4	RS-232 TX output to Keyboard		<b>YELLOW</b>
Pin 12	RS-232 RX input to Keyboard		<b>GREEN</b>
Pin 5	Fan +VE 12V		<b>RED</b> Fig.8
Pin 13	Fan GND		<b>Black</b> Fig.8
Pin 6	Do not connect		
Pin 14	Tamper/On/Blank connects via 4K7 resistor to Battery		
Pin 7	+VE 12 Volts	Sign power input	<b>THICK RED</b>
Pin 8	+VE 12 Volts	Sign power input	<b>THIN RED</b>
Pin 15	GND	Sign Power input	<b>THICK BLACK</b>
Pin 16	GND	Sign Power input	<b>THIN BLACK</b>

RADAR JST-4



VMS KEYBOARD



### PIN 14 VOLTAGE CHECKS:

With battery 11 to 13.8V and normal condition, Pin 14 should be 5.6 to 7.5V.

If this is not so, the Tamper Switch is faulty (open circuit) or connection to the battery via the 4K7 is broken.


When Switch is at BLANK, Pin 14 should be 0V or very close.

When Switch is at SHOW, Pin 14 should be same as battery voltage, so 11 to 13.8V

## EXPLANATION OF PIN 14 FUNCTION:

**PIN 14** -----(3)----- [optional switch (2)]-----{4K7(1)}-----Battery +12V

- (1) Pin connects via 4K7 1% resistor to the battery line and monitors system voltage. As a minimum, connect to the Main Battery.
- (2) If the Line is broken (SW1) a 'Tamper' alarm is registered. This line can be connected via lid switches.
- (3) Blank / Resume Message Function. (SW2)  
If Pin 14 is pulsed to GND the message BLANKS  
If Pin 14 is pulse to + 12V the message DISPLAYS.




**Data Signs**  
AUSTRALIA  
Since 1976

[datasigns.com](http://datasigns.com)  
1300 850 785




# VMS CONTROL PANEL





## JST CONNECTOR – 8 PIN

Pin 1	RS-232 RX to RM-32D	<b>GREEN</b>
Pin 5	RS-232 TX from RM-32D	<b>YELLOW</b>
Pin 2	Not used	
Pin 6	Tamper/On/Blank, V Sense	<b>RED</b>
Pin 3	Hoist Lift +	<b>BLUE</b> or Pump Raise
Pin 7	Hoist Lift -	<b>BROWN</b> or Release Valve
Pin 4	+VE 12V Input	<b>RED from FUSE PANEL</b>
Pin 8	GND	<b>BLACK from BATTERY</b>



Connects to PIN 14 of RM-32D Controller



VMS Keyboard Connector

## VMS COMPUTER CONNECTION BOARD

Pin 1	+12V	<b>RED 2-PAIR</b>
Pin 2	RS-232 RX to RM-32	<b>GREEN 2-PAIR</b>
Pin 3	RS-232 TX from RM-32	<b>YELLOW 2-PAIR</b>
Pin 4	GND	<b>BLACK 2-PAIR</b>

Note: VMS Computer Version 2.xx.xx is Legacy and not compatible with current controllers. Version 3.xx.xx can be upgraded via SD Card.



**Data Signs**  
AUSTRALIA  
Since 1976



[datasigns.com](http://datasigns.com)



1300 850 785

